


Packing Checklist

If you discover any item below damaged or lost, please contact your vendor.

- PMB-891LF x 1
- This Quick Reference Guide x 1
- Manual/Driver CD x 1
- Jumper (2.0 mm) x 3
- SATA Cable (460 mm) x 1
- I/O Shield x 1

PMB-891LF Quick Reference Guide




Ver. Q3

All Rights Reserved. Copyright 2014


Jumper Setting

RS232/422/485 (COM2) Selection




RS232 RS422 RS485 (default)



COM3 RI & Voltage Selection




COM4 RI & Voltage Selection




LAN Link LED Selection




COM2 Auto Detect Selection




Clear CMOS Data Selection



CPU Selection



Front Panel Selection




CAUTION! Danger of explosion if the battery is incorrectly replaced. Replace only with the same/equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

PMB-891LF

Intel® 3rd Gen. Core™ i7/i5/i3 & Pentium® ATX Motherboard

Front View



I/O View

