DRIVER UTILITY SP-6305_7_9 v1.0

===
======

  1. Click on the self-extracting and self-installing setup file and
      answer all prompts presented.

  2. You will be prompted to reboot when installation is complete.

  3.The sequence of setup is Main Chip --> VGA --> LAN --> SOUND --> TOUCH
===
======
  DRIVER CD CONTENT
===
======
  Driver\---+--->\Flash BIOS\afua.bat
              |
              |
              +--->\Platform\Win7,POSReady7(32-bit)\Main Chip\infinst_autol.exe
              |
              |
              +--->\Platform\VGA\Win7,POSReady7(32-bit)\VGA\Setup.exe
              |
              |

+--->\Platform\Win7,POSReady7(32-bit)\LAN\Install_Win7_7061_09202012\Setup.e
xe
              |
              |

+--->\Platform\Win7,POSReady7(32-bit)\SOUND\32bit_Vista_Win7_Win8_R270.exe
              |
              |
              +--->\Device\Touch Screen\Setup.exe

MANUAL\AdbeRdr930_en_US.exe (PDF File reader)

==
========

  1. System BIOS Update

      Users of AMI BIOS can use the program "AFUA.bat" contained in CD-ROM
      for BIOS update.

      a. This is found in CD:Driver\Flash BIOS\afua.bat

BIOS FLASH SETUP:

      a. Prepare a bootable flash drive and include DOS files: AFUDOS.EXE,AFUA.BAT
and "BIOS ROM file
          (ex.6305xxxx.ROM)" (*the flash drive need 4MB free space.)

      b. Use flash drive to boot, then type "AFUA 6305XXXX.ROM" and press enter to
automatically flash BIOS.
      (ex. C:\>afua 63050P01.ROM <enter>)

2. The system has LAN function (Realtek RTL8111F) that can support
     various network adapters. The content of the LAN driver is found as follows:

     a. Windows 7_32bit

3. The Realtek ALC888S HD Audio codec sound function enhanced in this system fully
compatible with
     Windows XP,   Windows Vista you will find the content of the Sound driver.

     a. Windows 7_32bit

4. The Main Chip directory is contained in CD-ROM for INTEL NM10 Driver.

a. Windows 7_32bit

5. The VGA interface (Intel(R) Graphic Driver) is embedded with our system to support
CRT display, Panel Link (optional) and TV-Out Encoder (optional). The following illustration briefly showa
you the content of VGA driver in sub-directory \VGA\

a. Windows 7_32bit

**** Third party trademarks or brand names are the property of their owners.****